

06 CAUTIONS

- 1 Please read these instructions carefully before using the lamp.
- 2 Please use only as directed.
- 3 Please don't allow any liquids to enter the machine or submerge the machine in water.
- 4 Please don't use the lamp if it is displaying any faults.
- 5 Please unplug the adapter when not in use.
- 6 Please don't use the lamp if the adapter has failed.
- 7 Please don't run the lamp continuously for more than 600 seconds, as this may reduce its lifespan.
- 8 Please don't look directly at the emitted light where possible.

PN SPECIALITY DUAL CURE LAMP - ST



USER MANUAL

www.planetnails.com.au




01 PACKING LIST

- PN Speciality Dual Cure Lamp - ST (main body)
- AC Adapter
- Instructions

02 PARTS INSTRUCTION

- 1 Infrared sensor
- 2 10S timing button
- 3 30S timing button
- 4 60S timing button
- 5 90S timing button (low heat mode/ hard gel setting)
- 6 DC power socket



03 PRODUCT INSTRUCTION

For professional use only.

04 OPERATION INSTRUCTION

- 1 Connect with the power adapter. Please only use the 24V 1A adapter supplied — if a different adapter is used the lamp will be damaged.
- 2 Default setting is 30S. In standby, the user can select cure times by pressing the 10S/30S/60S/90S (low heat mode) buttons.
- 3 10S/30S/60S modes are auto sensor modes. The infrared sensor will be activated when a hand is placed inside the lamp, switching on the LEDs, and will automatically switch off when the hand is removed or the selected time has lapsed.
- 4 90S is low heat mode. During low heat mode the power increases gradually over time to help prevent a heat spike during curing.

05 TECHNICAL INSTRUCTION

- 1 36 UV LEDs.
- 2 Rated Power: Max 30W - Power Irradiance: Equivalent to 54W CCFL lamp
- 3 AC input: 100V-240V 50/60Hz DC output: 24V 1A
- 4 Size: 201×207×110mm
- 5 Wave length: 365nm + 405nm

**Power irradiance of lamp indicates total LEDs rated power emitting UV radiation. The lamp uses high efficiency, energy saving, long-life UV/LED technology, equivalent to 54W CCFL irradiance.*